





RF Connector Assembly Guide

Install a type N clamping connector with a LMR400 RF coaxial cable

Tool you need: Cable knife, spanner, flat file,
wrench ,Scale



<p>1. Trim the cable, Dimension is 16MM, this dimension isn't fix, change by different model and cable. And put screw on Cable.</p>	
<p>2. Put Sleeve to cable, fold shield layer, trim useless shield layer.</p>	
<p>3. Insert washer</p>	
<p>4. Cut off insulation layer</p>	

5. Chamfer the inner conductor 0.5x45 for easy to insert cable conductor to pin of connector



6. Put on the body and use wrench to tightly.

